


## GOLD CROW 12 Quick Start Guide

### Read Before Using

#### Product Structure




#### Disclaimer

Gold crow12 is an airbag light made of TPU


1. Before use, make sure the airbag is filled with air before turning on the light. If you turn on the light directly without filling it with air, high temperature will occur and may cause damage to the airbag.
  2. Avoid contact with sharp objects, corrosive liquids and high-temperature substances during use, which may cause damage to the air bag.
  3. Although Gold Crow12 is an airbag light body, please try to avoid squeezing and falling from high altitude, which may also cause damage to the airbag.
- The above damages are outside our company's warranty, and our company has nothing to do with the secondary injuries and losses caused by this.

#### Product Use




### Safety Tips

1、 Please inflate the air before turning on the light.



①Inflate the lamp first




②After inflating, turn on the light

- 2、 When using it for the first time, please complete a charge-discharge cycle, that is, discharge it completely until the battery is exhausted and then fully charge it.
- 3、 The Type-C port prevents rainwater from splashing in.
- 4、 When this product is working, do not touch the magnetic suction area (i.e. the area with the "High Temperature Caution" mark).

### Effect Mode Introduction

<p><b>Constant light mode</b></p> <p>Light stays on</p>	<p><b>Bad TV Mode</b></p> <p>The light go into a simulated bad TV state. Random irregular brightness variations.</p>	<p><b>Bad Bulb Mode</b></p> <p>Simulate the flickering of a damaged light bulb flickering at random and high frequency.</p>
<p><b>Flashing Mode</b></p> <p>The more star icons, the faster the blinking. The less the star icon blinks, the slower it will be. Blinking is random.</p>	<p><b>Lightning Mode</b></p> <p>The light enters the lightning state, the more lightning icons, the denser the lightning speed, the lower the lightning interval, and the lightning is triggered randomly.</p>	<p><b>SOS Mode</b></p> <p>The light enters the state of SOS distress flashing, three short, three long and three short international distress lights.</p>
<p><b>Strobe mode</b></p>	<p><b>Flash mode</b></p>	



### Warranty Card

Shenzhen Yingzhiqi Technology Co.,Ltd  
 Room 705, Building 8, Area 41, No. 31, Jia'an Road, Haili Community, Xin'an Street, Bao'an District, Shenzhen  
 Tel: +86 40096 80096 86 18928447616  
 URL: www.in-kee.com



**INKEE**  
 Shenzhen Yingzhiqi Technology Co.,Ltd  
 Inspection: qualified

#### Warranty Card

Product Name	
Date of purchase	
Customer Name	
Telephone	
Address	