


## GC Air 12 Bi-color Temperature Light Tube Quick Start Guide

**Read Before Using**

### Product Structure




### Disclaimer

Gold crow12 is an airbag light made of TPU

- Before use, make sure the airbag is filled with air before turning on the light. If you turn on the light directly without filling it with air, high temperature will occur and may cause damage to the airbag.
  - Avoid contact with sharp objects, corrosive liquids and high-temperature substances during use, which may cause damage to the air bag.
  - Although Gold Crow12 is an airbag light body, please try to avoid squeezing and falling from high altitude, which may also cause damage to the airbag.
- The above damages are outside our company's warranty, and our company has nothing to do with the secondary injuries and losses caused by this.

### Product Use



### Safety Tips

1、Please inflate the air before turning on the light.




①Inflate the lamp first

②After inflating, turn on the light

- The Type-C port prevents rainwater from splashing in.
- When this product is working, do not touch the magnetic suction area (i.e. the area with the "High Temperature Caution" mark).
- Power on:** Short press the power button to light up the screen, then press and hold for 3 seconds to power on.
- Shut down:** Press and hold the power button to shut down.

### Effect Mode Introduction

<p><b>Constant light mode</b></p> <p>Light stays on</p>	<p><b>Bad TV Mode</b></p> <p>The light go into a simulated bad TV state, Random irregular brightness variations.</p>	<p><b>Bad Bulb Mode</b></p> <p>Simulate the flickering of a damaged light bulb, flickering at random and high frequency.</p>
<p><b>Flashing Mode</b></p> <p>The more star icons, the faster the blinking, the less the star icon blinks, the slower it will be. Blinking is random.</p>	<p><b>Lightning Mode</b></p> <p>The light enters the lightning state, the more lightning icons, the denser the lightning speed, the fewer the lightning icons, the longer the flashing interval, and the lightning is triggered randomly.</p>	<p><b>SOS Mode</b></p> <p>The light enters the state of SOS distress flashing, three short, three long and three short international distress lights.</p>
<p><b>Strobe mode</b></p>	<p><b>Flash mode</b></p>	



### Shenzhen Yingzhiqi Technology Co., Ltd

Address: Room 705, No.8, Zone 41, No.31 Jia'an Road, Haile Community, Xin'an Street, Bao'an District, Shenzhen, Guangdong China.

Tel: +86 40096 80096 Website: [www.in-kee.com](http://www.in-kee.com)

Latest version of the User Manual is available at Official Website:

<https://www.in-kee.com/en/user-manual-2/>

This manual is subject to update without prior notice. If you have any questions or suggestions about the manual, please contact us at the following email address: [info@in-kee.com](mailto:info@in-kee.com)



APP Download



Firmware Download



Official website QR code



WeChat Subscription